



RECTANGULAR WONDER BOX COOKER

- for oval crockpot -
- with loops -

- One way pattern across the grain
4.3 yds or 4 metres of 36" fabric
- One way pattern with the grain
6.7 yds or 6.15 metres of 36" fabric
OR 3.3 yds or 3.08 metres of 45" fabric



Sew top in pairs, then all 4 together, leaving opening to fill and adding loops for hanging.

Repeat with bottom.

★ NOTE: put the opening near the loop so you can hang it to fill.

The instructions are the same.
Feel free to contact me at:
<http://www.home-and-school-solutions.com>